PRESET TORQUE WRENCHES

ATTENTION: CLOCKWISE OPERATION ONLY

- Ratchet head
- Torque is preset, to prevent adjustment by mistake during use
- The torque is set at the factory before delivery. Customers can also set the torque with torque adjustment tool (**IST-PW-TOOL**, **optional**) and digital torque testers (**IST-TT□□□**, **optional**)
- Clockwise operation only



IST-PW20



torque adjustment tool (**optional**)

SPECIFICATION

Code	IST-PW12	IST-PW20	IST-PW30	IST-PW60	IST-PW125	IST-PW200
Adjustable range*	2.5~12N.m 22~105in.lb	4~20N.m 36~175in.lb	6~30N.m 55~265in.lb	10~60N.m 8~44ft.lb	25~125N.m 20~90ft.lb	40~200N.m 30~145ft.lb
Accuracy	±3%	±3%	±3%	±3%	±3%	±3%
Square driver (D)	1/4"	1/4"	3/8"	3/8"	3/8"	1/2"
Length	184mm	184mm	214mm	255mm	366mm	457mm
Weight	450g	450g	500g	560g	790g	1200g

Code	IST-PW340	IST-PW500	IST-PW650	IST-PW800	IST-PW1000A	IST-PW1000B
Adjustable range*	65~340N.m 50~250ft.lb	100~500N.m 75~365ft.lb	150~650N.m 110~475ft.lb	160~800N.m 120~585ft.lb	200~1000N.m 150~735ft.lb	200~1000N.m 150~735ft.lb
Accuracy	±3%	±3%	±4%	±4%	±4%	±4%
Square driver (D)	1/2"	3/4"	3/4"	3/4"	3/4"	1"
Length	691mm	910mm	910mm	1037mm	1265mm	1265mm
Weight	1960g	2800g	2800g	5000g	6000g	6000g

OPTIONAL ACCESSORY

Torque adjustment tool	IST-PW-TOOL

*Adjust to a fixed torque value according to customer requirements before delivery

SLIP TYPE PRESET TORQUE WRENCHES

INSPECTION CERTIFICATE

ATTENTION: CLOCKWISE OPERATION ONLY

- Ratchet head
- Once set torque is achieved, even if more force is applied, wrench does not add additional torque and prevent over-torque
- Torque is preset, to prevent adjustment by mistake during use
- The torque is set at the factory before delivery, customers can also set the torque with torque adjustment tool



IST-36WM60

SPECIFICATION

Code	IST-36WM6	IST-36WM25	IST-36WM60	IST-36WM100
Adjustable range*	1~6N.m	5~25N.m	10~60N.m	20~100N.m
Accuracy	±6%			
Square driver (D)	1/4"	1/4"	3/8"	1/2"
Length	200mm	220mm	330mm	460mm
Weight	410g	510g	820g	1060g

OPTIONAL ACCESSORY

Torque adjustment tool	IST-36WM-TOOL1 (suitable for **IST-36WM6**)
	IST-36WM-TOOL2 (suitable for **IST-36WM25**)
	IST-PW-TOOL (suitable for **IST-36WM60**, **IST-36WM100**)

*Adjust to a fixed torque value according to customer requirements before delivery



torque adjustment tool (**optional**)