



ISO	R	L	H1 H	B	F	L1	L2	λS	Y0	Insert	Screw	Torx Key
1031500	•	•	16	16	21	125	25	0	0	RC.T 0803..	M3X9	T10
1031600	•	•	20	20	25	125	35	0	0			
1031700	•	•	25	25	32	150	40	0	0			
1031800	•	•	16	16	21	100	25	0	0	RC.T 10T3..	M4X11	T15
1031900	•	•	20	20	25	125	35	0	0			
1032000	•	•	25	25	32	150	40	0	0			
1032100	•	•	32	32	40	170	40	0	0	RC.T 1204..		
1032200	•	•	16	16	21	100	25	0	0			
1032300	•	•	20	20	25	125	35	0	0			
1032400	•	•	25	25	32	150	40	0	0			
1032500	•	•	32	32	40	170	40	0	0			