



- ◆ Birincil açı, 1/2 birincil açı ve tümler açı kontrolü


Kod	Adet	Hassasiyet
932-018-01	18	±10'

Birincil açı	½ birincil açı	Tümler açı
5°	2°30'	175°
10°	5°	170°
15°	7°30'	165°
20°	10°	160°
25°	12°30'	155°
30°	15°	150°
35°	17°30'	145°
40°	20°	140°
45°	22°30'	135°
50°	25°	130°
55°	27°30'	125°
60°	30°	120°
65°	32°30'	115°
70°	35°	110°
75°	37°30'	105°
80°	40°	100°
85°	42°30'	95°
90°	45°	90°




941 SERİSİ

RADYÜS MASTARI



941-015-32

- ◆ Radyüs kontrolü
- ◆ İç ve dış ölçüm yüzeyleri



Kod	Aralık	Adet	Hassasiyet	Radyüs ölçüleri (mm)
941-007-34	1 - 7mm	17x2	±0.03mm	1, 1.25, 1.5, 1.75, 2, 2.25, 2.5, 2.75, 3, 3.5, 4, 4.5, 5, 5.5, 6, 6.5, 7
941-015-32	7.5 - 15mm	16x2	±0.035mm	7.5, 8, 8.5, 9, 9.5, 10, 10.5, 11, 11.5, 12, 12.5, 13, 13.5, 14, 14.5, 15
941-025-30	15.5 - 25mm	15x2	±0.042mm	15.5, 16, 16.5, 17, 17.5, 18, 18.5, 19, 19.5, 20, 21, 22, 23, 24, 25